

RD13 INSTALLATION SHEET

Installation Applications

Stone



If coring into stone, cut hole with diameter of 2". Place light directly into hole, no need for the use of sleeve

Concrete



If pouring concrete, build wiring protection channel using standard PVC pipe.
Fit light into standard 1.5" PVC Coupler.

Dirt



Arrange wiring within dirt from power source, make hole in dirt and place light.
Fitted inside sleeve into dirt.

Thing to Consider

- Manage Voltage Drop (Use appropriate wire gauge size to get the correct voltage at the light source).
- Test each light at their installation location before permanent installation.
- Make sure all wire connection points is protected from water (If water on wire, will cause premature failure).
- Wiring can be done by homerun cable (1 wire from power supply to one light) or by using the same cable by jumping from one light to the next

